

EMERGENCY CALL POINT

OPERATING INSTRUCTIONS

IN CASE OF EMERGENCY



- The Call Point is available if the System OK light is solid and not flashing.
- Press the 'CALL' button to initiate a call.
- The STATUS light will illuminate and a ring tone will sound.
- When the call is answered the Ring tone will stop and the Status Light will stay illuminated to show the call is in progress.
- Wait for the operator to finish speaking before replying.
- Speak clearly in the direction of the unit. Do not press or hold the 'CALL' button during a call.
- When the conversation finishes the STATUS light will go out and the SYSTEM OK light will illuminate.
- If you want to speak to the operator again press the 'CALL' button.