

## How to diagnose faults at the panel using control buttons

<b>Product Range:</b>	Omicare
<b>Product Code (if applicable):</b>	BVOC4M / BVOC4MS / BVOC8M / BVOC8MS / BVOC16M / BVOC16MS / BVOC32M / BVOC32MS / BVOC48 / BVOC48S / BVOC64 / BVOC64S / BVOC80 / BVOC80S / BVOC96 / BVOC96S / BVOC112 / BVOC112S / BVOC128 / BVOC128S
<b>Description of activity:</b>	Diagnosing panel faults
<b>Descriptions of likely fault:</b>	<ul style="list-style-type: none"> <li>Yellow fault LED(s) flashing in one or more zones.</li> </ul>

Please Note: "Inspection and servicing needs to be carried out by a competent person with specialist knowledge of the equipment used. This will normally be an outside organization; care needs to be taken to ensure that, if, for example, in-house employees are used for this task, they have equivalent competence to the technicians of a typical servicing organisation." (BS5839-9).

### Description of rectification works:

**ENSURE WHEN POWERING OFF THE SYSTEM TAKE THE BATTERIES OFF FIRST THEN THE MAINS AND WHEN POWERING BACK ON PUT THE BATTERIES ON FIRST THEN MAINS TO NOT CREATE A FUSE FAULT.**

1. If a fault LED is flashing in one or more zones:
2. Press the SPEAK button and hold it in.
3. If the yellow LED is extinguished, then it is a DATA fault.
4. Re run commission and note where sequence ceases and investigate a possible break.
5. If pressing SPEAK does not extinguish yellow LED.
6. Press and hold the ALL button.
7. If fault light extinguishes then the issue is a POWER fault or a DTA fault (if this is the device at that location).
8. In the case of a power fault check the return voltage, no more than 8 volt drop from the out leg to the return is permissible. If the drop is 8 volts or more investigate the loop where the commission sequence ceased.
9. If it is a DTA fault.
10. Check the wiring is correct. Check that if only one DTAKIT fitted with one ODL, one RP and one PC that switch 9 has not been moved to OFF.
11. If a BVOCRIF needs to be moved ensure the panel reset is held in for 10 seconds after the switch has been moved to acknowledge the change in status.

<b>Author:</b>	Ashley Wright
<b>Approved by:</b>	Ashley Wright
<b>Date:</b>	24/02/2020

**For further help:**

**Manuals & Guides:** technical manuals, installation guides and more are available for download on our website: [baldwinboxall.co.uk/downloads](http://baldwinboxall.co.uk/downloads).

**Telephone:** technical help line (0)1892 664422 (then press 3 for after sales technical help).

**Training:** we hold a range of courses at different levels for engineers. To find out more, or place a booking, please visit our website: [baldwinboxall.co.uk/training](http://baldwinboxall.co.uk/training) or contact Carol [@baldwinboxall.co.uk](mailto:carol@baldwinboxall.co.uk).



**BALDWIN BOXALL**  
LEADING THE WAY TO SAFETY

Baldwin Boxall Communications Ltd  
Wealden Industrial Estate, Farningham Road,  
Crowborough, East Sussex, TN6 2JR, United Kingdom

T: +44 (0) 1892 664422 F: +44 (0) 1892 663146  
E: [mail@baldwinboxall.co.uk](mailto:mail@baldwinboxall.co.uk)  
W: [www.baldwinboxall.co.uk](http://www.baldwinboxall.co.uk)