

Product

BDM300

Operating Instructions

Baldwin Boxall Communications Ltd.

Wealden Industrial Estate, Farningham Road
Crowborough, East Sussex, TN6 2JR

Telephone: 01892 664422 Fax: 01892 663146

Website: www.baldwinboxall.co.uk

Email: mail@baldwinboxall.co.uk

BALDWIN BOXALL
COMMUNICATIONS

BDM 300

The BDM 300 microphone is designed to be used with our MITRE and ADEPT and VIGIL amplifier range. The microphone unit can be desk or wall mounted and is fitted with our standard dynamic cardioid microphone. It also provides a single press-to-talk button and a 25 way D plug which will interface with a BM25 Socket Box.

Technical Specification

Output impedance	200 Ohms
Sensitivity	-78dB @ 1KHz ref 0dB = 1v/microbar
Frequency response	100Hz – 10KHz

BDM300 CONNECTIONS

The microphone is terminated to a 25 way 'D' connector. It is supplied with a BMS25 single gang socket box and connections are made using the screw terminals.

FUNCTION

BMS 25 CONNECTIONS

AUDIO -	Output floating	16
CABLE SCREEN -	Connect to 0V	17
AUDIO -	Output floating	18
0V		19
ACCESS -	Connects to 0V when press-to-talk button operated	21